



GOLF FLAG DISPLAY CASE ASSEMBLY INSTRUCTIONS



Visit www.mframing.com/golf and watch a video on case assembly and hanging tips.

1. Place case face down on a soft surface (carpet or a towel work great). Bend back flexible tabs and remove backing components.

2. Remove small magnets from board and set aside being careful not to misplace.

3. Position golf flag on mounting board making sure it is centered and straight.

4. Using magnets, attach flag to board by placing one magnet on top of the flag and the other on the bottom side of board. You will feel the magnets link together as a connection is made. See "Figure A" below for suggested magnet layout.

5. Place backing components back inside of frame. Take note of hanging hardware to ensure proper orientation of display. Bend down black flexible tabs.

6. Hang display on your wall and enjoy!




Figure A