



HOLE-IN-ONE DISPLAY CASE ASSEMBLY INSTRUCTIONS



Visit www.mframing.com/golf and watch a video on case assembly and hanging tips.

1. Place case face down on a soft surface (carpet or a towel work great). Bend back flexible tabs and remove backing components. Set black backing board aside and use green matting for steps 2 - 4.

* 2. Using a strip of tape, mount plaque to back side of plaque window facing forward. Make sure it is centered and straight before firmly pressing down tape.

3. (skip this step if your case model does not have a 5" x 7" photo window) Using a strip of tape, mount a 5" x 7" photo to back side of photo window facing forward. Make sure it is centered and straight before firmly pressing down tape.

4. (skip this step if your case model does not have a scorecard) Remove release paper strip from scorecard mounting board. Attach scorecard making sure it's centered and straight. Press down firmly.

5. Remove release strip from back side of green suede board and firmly attach to black backing board. Make sure the golf ball cutouts are properly centered.

6. Pressure fit golf ball in circular opening from the front side of board. Make sure ball is snug and do not press too hard. Ball should not pop through opening.

7. Place backing components back inside of frame. Take note of hanging hardware to ensure proper orientation of display. Bend down black flexible tabs.

8. Hang display on your wall and enjoy!

* *Don't have a plaque? Order one for FREE on our website: www.mframing.com/plaque You're welcome to have a plaque made elsewhere. We recommend having it sized to 5 1/2" x 2" and attaching directly to the black backing board.*